


Series	Poles-Positions
	SD12 1-2, 1-3
	SE14 1-4
	SSS 1-2
	LSS 1-2, 2-2
	SS3 1-2
	SS4 1-3
	MSS3, MSS4 1-2, 1-3
	MSS6, MSS14 2-2, 1-4
	S2S 1-2, 1-3
	SC12P 1-2
	ZSS 1-2
	NSS 1-3